



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		806235A	1 HOUSING ASSEMBLY-Thermostat	1		
2	22	32803	PLUG-Pipe (3/8 in.)	2		
3	27	806871	GASKET-Thermostat	1		1,2
4	27	53045 1	GASKET-Thermostat Housing	1		1,2
5		807252	2 THERMOSTAT	1		
6	23	806922	SLEEVE	1		
7	10	98794	SCREW (3/8-16 x 1 in.)	2		
8	32	17435 79	HOSE-Sea Water Pump to Drive U	1		
9	32	807404	HOSE-Power Steering Oil Cooler tc	1		
10	32	807407	1 HOSE-Thermostat Housing to Engit	1		
11	32	807405	HOSE-Engine Oil Cooler to Power E	1		
12	54	815504222	CLAMP	8		
13	32	89718	1 HOSE-Thermostat Housing to Wate	1	(7.4L BRAVO)	
13	32	89718	3 HOSE-Thermostat Housing to Wate	1	(454 MAGNUM)	
14	54	815504232	CLAMP	2		
15	32	89749	1 HOSE-Thermostat Housing to Port I	1		
16	32	89730	1 HOSE	1	Thermostat Housing to Starboard E	
17	54	815504220	CLAMP	4		
18	54	806616	CLAMP	1		
19		99356A	2 COOLER-Power Steering Oil	1		
20		807402T	BRACKET	1		
21		807445T	CLAMP	1		
22	12	35462	WASHER	1		
23	11	72008	NUT (1/4-20)	1		
24	10	86750	SCREW (5/16-18 x 5/8 in.)	1		
25	13	39107	WASHER	1		
-	27	850470A96	GASKET SET-Overhaul	1	(7.4L BRAVO)	
-	27	850465A96	GASKET SET-Overhaul	1	(454 MAGNUM)	