



Parts List

| Ref | Class | Part | Description | Qty | Comment | Footnote |
|-----|-------|----------|-----------------------------|-----|---------|----------|
| 1 | | 16413A 3 | THERMOSTAT HOUSING | 1 | | |
| 2 | 22 | 32803 | PIPE PLUG | 1 | | |
| 3 | 10 | 17989 | SCREW | 1 | | |
| 4 | 24 | 75533 | SPRING | 2 | | |
| 5 | 30 | 98475 | NYLON BALL | 2 | | |
| 6 | 11 | 29488 | NUT | 1 | | |
| 7 | 25 | 30224 | O-RING | 1 | | 4 |
| 8 | 27 | 53045 1 | GASKET | 1 | | 4 |
| 9 | | 59137 | THERMOSTAT (143) | 1 | | |
| 10 | 23 | 17495 | SLEEVE | 1 | | |
| 11 | 27 | 33179 2 | GASKET | 2 | | 4 |
| 12 | | 17494A 1 | COVER | 1 | | |
| 13 | 10 | 60410 | SCREW | 2 | | |
| 14 | 13 | 35048 | LOCKWASHER | 2 | | |
| 15 | 32 | 33220 70 | HOSE (STARBOARD/PORT) | 2 | | |
| 15 | 32 | 33220 70 | HOSE (STARBOARD) | 1 | | 8 |
| 15 | 32 | 817433 | HOSE (MOLDED - PORT) | 1 | | 1 |
| 16 | 54 | 32780 | CLAMP | AR | | 1 |
| 17 | 32 | 18320 | HOSE, OIL COOLER TO SEA PUM | 1 | | |
| 18 | 54 | 47715 | CLIP | 2 | | |
| 19 | 32 | 16011 1 | HOSE, THERMOSTAT HOUSING | 1 | | |
| 20 | 32 | 89718 | HOSE, THERMOSTAT HOUSING | 1 | | |
| 21 | 54 | 87268 | CLAMP | 2 | | |
| 22 | 32 | 89749 1 | HOSE, THERMOSTAT COVER (P) | 1 | | |
| 23 | 32 | 89730 1 | HOSE, THERMOSTAT COVER (S) | 1 | | |
| 24 | | 12552 | LIFTING EYE | 1 | | |
| 25 | 32 | 17435 70 | HOSE, SEA PUMP TO DRIVE UNI | 1 | | |