



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		66418T	BRACKET	2	FRONT	
2	10	68101	SCREW (3/8-16 X 1-3/8 IN.)	2		
3	16	805357	STUD	4		
4	10	37269	SCREW (7/16-14 X 2 IN.)	2		
5	13	32993	LOCKWASHER (7/16 IN.)	2		
6	11	29553	NUT (7/16-14)	2		
7		66166A 4	TRUNNION	2		
8	13	68102	LOCKWASHER (3/4 IN.)	2		
9		66284A 2	BASE-ENGINE END	2	FRONT	
10	11	20739	NUT-JAM (3/4-16)	2		
11	14	66658	WASHER-TAB	2		
12	11	20739	NUT-JAM (3/4-16)	2		
13	10	40097 60	SCREW (M12-1.75 X 60)	4		
14	10	57357	SCREW (7/16-14 X 2-1/4 IN.)	2		
15		805496T	BRACKET	1	PORT, DOWN ANGLE TRANSMI	
15		805496T 1	BRACKET	1	STARBOARD, DOWN ANGLE TF	
15		807724T	BRACKET	1	PORT, V-DRIVE TRANSMISSION 1	
15		807725T	BRACKET	1	STARBOARD, V-DRIVE TRANSM 1	
16	13	32993	LOCKWASHER (7/16 IN.)	2		
17	11	29553	NUT (7/16-14)	2		
18		66166A 4	TRUNNION	2		
19	13	68102	LOCKWASHER (3/4 IN.)	2		
20		816326A 2	BASE-TRANSMISSION END	2	REAR	
21	11	816331	NUT-JAM (3/4-16)	2		
22	14	66658	WASHER-TAB	2		
23	11	20739	NUT-JAM (3/4-16)	2		