



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		818383T	PUMP-Fuel	1		
2	27	34213	GASKET-Fuel Pump	1		1
3	10	34354	SCREW (3/8-16 x 1-1/2 in.)	2		
4	13	35048	LOCKWASHER (3/8 in.)	2		
5	22	43276	FITTING-Elbow (90 Degrees)	2		
6		89876A 3	BASE ASSEMBLY	1		
7	22	32561	PLUG-Pipe (1/4-18)	2		
8	22	816133 1	FITTING	1		
9	11	29250	NUT (5/16-24)	2		
10	35	807172	FILTER-Fuel/Water Separator	1		
11	22	42897	FITTING (Straight)	1		
12	32	805637T	FUEL LINE-Filter to Pump	1	(SEE "FUEL COOLER" FOR FUE	
13	32	807079T	FUEL LINE-Fuel Pump to VST	1	(USE W/O FUEL COOLED SYST	
13	32	807732T 3	FUEL LINE-Fuel Pump to VST	1	(USE WITH FUEL COOLED SYS	
14		805556T 1	BRACKET-Fuel Filter Base	1		
15	32	73815 67	TUBING-Fuel Pump to T-fitting	1		
16	54	806617	CLAMP-Fuel Line	1		
17	22	46982	FITTING-Elbow (90 Degrees) (Inlet	1		
-	27	811572A94	GASKET SET-Overhaul	1		