



19731

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	50	99419A 3	STARTER MOTOR ASSEMBLY	1		
2	11	34933	NUT, (.437-20), STARTER MOTOR	2		
3	12	45176	WASHER, (.453 x .812 x .105), ST	2		
4	16	57982	STUD, (.437-14/ 437-20 x 1.875), S	2		
5	11	32219	NUT, (.375-16), STARTER TERMIN	1		
6	13	26995	LOCKWASHER, (#8), STARTER T	2		
7	11	26419	NUT, (#8-32), STARTER TERMIN	2		
8		78403A 2	ALTERNATOR ASSEMBLY (39 AM	1	EARLY MODELS	
8		92497A 3	ALTERNATOR ASSEMBLY (55 AM	1	EARLY MODELS	
9	13	26996	LOCKWASHER, (#10), ALTERNA	1		
10	11	30968	NUT, ALTERNATOR TERMINAL	1		
11	13	26992	LOCKWASHER, (.250), ALTERNA	1		
12	11	64015	NUT, (.250-20), ALTERNATOR TE	1		
13		85013	BRACE, ALTERNATOR ADJUSTI	1		
14	10	47462	SCREW, (.437-14 x 1.250), ALTER	1		
15	13	47659	LOCKWASHER, (.437), ALTERNA	1		
16	12	30315	WASHER, ALTERNATOR BRACE	1		
17	10	29198	SCREW AND LOCKWASHER, (.31	1		
18	12	26168	WASHER, ALTERNATOR BRACE	1		
19		57908 11	SLEEVE, ALTERNATOR LEADS	1		
20		47487A 2	BRACKET, ALTERNATOR MOUN	1		
21	10	34353	SCREW, (.375-16 x 1.00), ALTERN	2		
21	10	45754	SCREW, ALTERNATOR BRACKE	1		
22	13	35048	LOCKWASHER, (.375), ALTERNA	3		
23	10	48308	SCREW, (.375-24 X 3.75), ALTERN	1		
24	12	20553	WASHER, (.406 x .734 x .063), AL	2		
25	23	33186	BUSHING, ALTERNATOR TO BR	1		
26	11	23161	NUT, (.375-24), ALTERNATOR SC	1		
27	85	79695	BOOT, Insulator (Black), STARTE	1		