



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	84	847722A 1	HARNES ASSEMBLY-Wiring	1		
2		26079A 2	PLATE KIT	1		
3	10	15001	SCREW (#8-16 x 7/8")	4		
4		847676 1	BRACKET-Mount (3/8")	1	SERIAL 0D763732-0F213123	
4		848131 1	BRACKET-Mount (7/16")	1	SERIAL 0F213124-0F213244	
5	88	11178	BREAKER-Circuit (50 AMP)	1		
6	13	26996	LOCKWASHER (#10)	2		
7	11	68219	NUT (10-32)	2		
8	10	45862	SCREW (10-32 x 7/8")	2		
9	11	61356	NUT (10-32)	2		
10	89	825842A 1	SOLENOID ASSEMBLY-Starter	1		
11	25	818967	GROMMET	2		
12	23	818968	BUSHING	2		
13	12	29245	WASHER	2		
14	13	26992	LOCKWASHER (1/4")	2		
15	10	76630	SCREW (1/4-20 x 1")	2		
16	13	26995	LOCKWASHER (#8)	2		
17	11	26419	NUT (8-32)	2		
18	13	26992	LOCKWASHER (1/4")	2		
19	11	94330	NUT (1/4-20)	2		
20		13611	SENDER UNIT-Oil Temperature	1		
21	13	26996	LOCKWASHER (#10)	1		
22	11	45076	NUT (10-32)	1		
23	22	36492	REDUCER	1		
24		97257A 1	SENDER ASSEMBLY-Water Temp	1		
24		49734A 1	SENDER ASSEMBLY-Water Temp	OPT.		3
25	13	26996	LOCKWASHER (#10)	1		
26	11	45076	NUT (10-32)	1		
27		815425	SENDER ASSEMBLY-Oil Pressure	1		
27		37293	SENDER ASSEMBLY-Oil Pressure	OPT.		3
28	13	26996	LOCKWASHER (#10)	1		
29	11	45076	NUT (10-32)	1		
30	22	64013	REDUCER	1		
31		42600A 3	CONTROLLER ASSEMBLY	1		
32	12	30164	WASHER	2		
33	13	26996	LOCKWASHER (#10)	7		
34	10	41771	SCREW (10-24 x 7/8")	2		
35	10	62568	SCREW (10-16 x 3/8")	1		
36	11	68219	NUT (10-32)	4		
37	84	86322A17	CABLE ASSEMBLY (Black)	1		
38		17216A 1	IGNITION MODULE ASSEMBLY	1		