



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	628	6100	CONNECTING ROD ASSEMBLY	4		
2	10	75444	SCREW, CONNECTING ROD CAP	8		
3	11	64789	NUT, CONNECTING ROD CAP	8		
4		68704A 1	BEARING, CONNECTING ROD (S	4		
4		68704A 2	BEARING, CONNECTING ROD (O	AR		
4		68704A 4	BEARING, CONNECTING ROD (O	AR		
4		68704A 3	BEARING, CONNECTING ROD (O	AR		
5	759	8312 10	PISTON ASSEMBLY (STD.)	4		
5	759	8312 11	PISTON ASSEMBLY (.005 O.S.) - L	AR		
5	759	8312 12	PISTON ASSEMBLY (.030 O.S.)	AR		
6	39	75422	RING, PISTON (STD.)	4		
6	39	75423	RING, PISTON (.030 O.S.)	AR		
7	462	7416	CAMSHAFT,(L.H. ROTATION)	1		
7	462	7567	CAMSHAFT,(R.H. ROTATION)	1		
8	28	86466	KEY, CAMSHAFT	1		
9	23	67484	BEARING, CAMSHAFT	5	WHEN ORDERING REPLACEME	
10		67492	THRUST PLATE, CAMSHAFT	1		
11	10	49668	SCREW, THRUST PLATE ATTAC	2		
12		86461	SPROCKET, CAMSHAFT	1		
13	10	70084	SCREW, SPROCKET TO CHAMSH	3		
14		68717	CHAIN, TIMING	1		
15		75202	TENSIONER, CHAIN	1		
16	23	75087	BUSHING, CHAIN TENSIONER (L	1		
17	10	75206	SCREW, TENSIONER ATTACHIN	1		
16	23	88431	BUSHING, CHAIN TENSIONER (R	1		
17	10	22441	SCREW, TENSIONER ATTACHIN	1		
18		56153	TAPPET	8		