



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		90334	FLYWHEEL HOUSING ASSEMBLY	1	
2	10	68101	SCREW, FLYWHEEL HOUSING A	3	
2	10	68101	SCREW, FLYWHEEL HOUSING A	4	
2	10	47688	SCREW, FLYWHEEL HOUSING A	2	
3	13	37459	LOCKWASHER, HOUSING ATTACH	7	
3	13	37459	LOCKWASHER, HOUSING ATTACH	6	
4	16	64066	STUD, FLYWHEEL HOUSING ATTACH	1	
5	12	46132	WASHER, FLYWHEEL HOUSING ATTACH	1	
6	11	32219	NUT, FLYWHEEL HOUSING ATTACH	1	
7		78110	COVER, FLYWHEEL HOUSING	1	
8	10	20031	SCREW, FLYWHEEL HOUSING COVER	7	
9	13	26992	LOCKWASHER, FLYWHEEL COVER	7	
10	27	88983	GASKET, FLYWHEEL HOUSING COVER	1	1
11		88984	SEAL, FLYWHEEL HOUSING COVER	1	
12		45915	TERMINAL BLOCK	1	
13	10	20189	SCREW, TERMINAL BLOCK TO FLYWHEEL	1	
14	11	27164	NUT, TERMINAL BLOCK TO FLYWHEEL	1	
15	10	62568	SCREW, LEAD ATTACHING TO TERMINAL BLOCK	1	
16		77932	BRACKET, CIRCUIT BREAKER	1	
17	10	47461	SCREW, CIRCUIT BREAKER BRACKET	2	
18	13	37272	LOCKWASHER, CIRCUIT BREAKER BRACKET	2	
19	12	22248	WASHER, CIRCUIT BREAKER BRACKET	2	
20	88	78813	CIRCUIT BREAKER	1	
21	10	24637	SCREW, CIRCUIT BREAKER TO TERMINAL BLOCK	2	
22	11	46438	NUT, CIRCUIT BREAKER TO TERMINAL BLOCK	2	
23	13	26996	LOCKWASHER, CIRCUIT BREAKER TO TERMINAL BLOCK	2	
24	11	68219	NUT, CIRCUIT BREAKER TERMINAL BLOCK	2	