



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		89953A 2	INTAKE MANIFOLD ASSEMBLY	1		
2	22	36382	PLUG INTAKE MANIFOLD-TOP	1		
3	22	32802	PLUG PIPE (1/8-27)	1		
4	10	28642	SCREW,DRIVE-WATER TUBE F	2		
5	27	70905	GASKET,INTAKE MANIFOLD	1		1
6	10	68101	SCREW,INTAKE MANIFOLD TO C	7		
7	12	25909	WASHER,INTAKE MANIFOLD SCI	7		
8		78801	LEVER,INTERMEDIATE THROTT	1		
9	12	35950	WASHER,INTERMEDIATE THRO	1		
10	12	30164	WASHER,INTERMEDIATE THRO	1		
11	11	20110	NUT,INTERMEDIATE THROTTLE	1		
12	10	38507	SCREW,LEVER TO INTAKE MANI	1		
13	12	20553	WASHER,LEVER SCREW	1		
14	12	57792	WASHER,LEVER SCREW	1		
15		27947	SWIVEL,LINKAGE	1		
16		64804	LINK ROD,LINKAGE	1		
17		63145A 1	LINK ROD ASSEMBLY, LINKAGE	1		
18		38983	SWIVEL,LINKAGE-CARBURETOR	1		
19	12	35950	WASHER,SWIVEL LINKAGE-CAR	1		
20	12	30164	WASHER,SWIVEL LINKAGE-CAR	1		
21	11	20110	NUT, SWIVEL LINKAGE-CARBUR	1		
22	16	38525	STUD,THROTTLE CABLE ANCHC	1		
23	12	24664	WASHE,THROTTLE CABLE ANCH	2		
24	11	20664	NUT,THROTTLE CABLE ANCHOF	1		
25	10	64969	SCREW,THROTTLE STOP	1		
26	11	33122	NUT,THROTTLE STOP SCREW	1		
27	32	76326	HOSE,INTAKE MANIFOLD TO WA	1		
28	54	32780	CLAMP,HOSE TO WATER PUMP	1		
29	54	32781	CLAMP,HOSE TO INTAKE MANIF	1		
30	32	76327	HOSE,INTAKE MANIFOLD (MCM)	1		
30	32	78072	HOSE,INTAKE MANIFOLD (INBOA	1		
31	54	32781	CLAMP,HOSE TO INTAKE MANIF	1		
32	54	32780	CLAMP,HOSE TO INTAKE MANIF	1		