



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		65534A 2	GIMBAL RING ASSEMBLY	1		
2	31	32538	BEARING, ROLLER5 - GIMBAL R	1		
3	26	32541	OIL SEAL, GIMBAL RING	2		
4	23	39273	SPACER, GIMBAL RING	1		
5	22	23612	FITTING, GREASE - GIMBAL RIN	3		
6		29359	LUBRICAP, GIMBAL RING GREZ	3		
7		65547	PIN, HINGE - GIMBAL RING TO BI	2		
8		64947	SENDER, DUMMY (STARBOARD)	1		
9	84	70967	HARNESS, DUMMY SENDER	1		
10	10	46942	SCREW, HARNESS ATTACHING	2		
8		63115A 2	SWITCH ASSEMBLY, TRIM LIMIT	1		
9	84	70968	HARNESS, TRIM LIMIT SWITCH	1		
10	10	63400	SCREW, HARNESS ATTACHING	2		
11	85	63990	INSULATOR, SWITCH AND SENC	2		
12	10	37978	SCREW, SWITCH AND SENDER	4		
13	13	26996	LOCKWASHER, SWITCH AND SE	4		
14		57008	RETAINER, SWITCH AND SENDE	4		
15		66546A 1	STEERING LEVER ASSEMBLY	1		
16	23	52698	SLEEVE, STEERING LEVER	1		
17		65537	SHAFT, UPPER SWIVEL	1		
18	53	72413	RETAINING RING, UPPER SWIVE	1		
19	11	25599	NUT, UPPER SWIVEL SHAFT	1		
20	22	32561	PLUG, PIPE - UPPER SWIVEL SH	1		
21	12	47683	WASHER, UPPER SWIVEL SHAF	1		
21	12	32997	WASHER, UPPER SWIVEL SHAF	2		
22	10	32995	SCREW, STEERING LEVER TO U	1		
23	11	20696	NUT, STEERING LEVER TO UPPI	1		
24		68291A 2	STEERING LINK ROD ASSEMBLY	1		
25	23	52698	SLEEVE, STEERING LINK ROD	1		
26	12	20086	WASHER, STEERING LINK ROD	1		
27	12	46132	WASHER, STEERING LINK ROD	1		
28	11	55438	NUT, STEERING LINK ROD	2		
29	18	45882	COTTER PIN, STEERING LINK I	2		