



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1	32	52951A	TUBING, HYDRAULIC PUMP TO F	1		
2	22	49718	FITTING, NUT - HYDRAULIC TL	4		
3	32	55816	HOSE, HYDRAULIC - CONNECTO	1		
4	54	45806	CLAMP, HYDRAULIC HOSE TO TI	1		
5	10	35519	SCREW, HYDRAULIC HOSE CLA	1		
6	32	59842	HOSE, HYDRAULIC - CONNECTO	1		
7	32	68676	HOSE, HYDRAULIC - CONNECTO	4		
8		45706A	TRIM CYLINDER ASSEMBLY, COI	2		
-		45522A	PIVOT END REPAIR KIT, TRIM	2		
-		45706A	OUTER TUBE REPAIR KIT, TRI	2		
-	25	60342A	"O" RING REPAIR KIT, TRIM CY	2		
9	17	45735	PIN, FRONT ANCHOR - TRIM CYL	1		
10	12	45737	WASHER, FRONT ANCHOR PIN	2		
11	23	61290	BUSHING, RUBBER - FRONT ANCH	4		
12	24	46312	SPRING, FRONT ANCHOR PIN	2		
13	24	46765	WASHER, FRONT ANCHOR PIN	2		
14	11	34932	NUT, FRONT ANCHOR PIN	2		
15	17	45738	PIN, REAR ANCHOR - TRIM CYLI	1		
16	12	45737	WASHER, REAR ANCHOR PIN	2		
17	23	61290	BUSHING, RUBBER - REAR ANCH	4		
18	24	46312	SPRING, REAR ANCHOR PIN	2		
19	12	46765	WASHER, REAR ANCHOR PIN	2		
20	11	34932	NUT, REAR ANCHOR PIN	2		