



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		71903A 2	FRONT COVER ASSEMBLY	1		
2	26	89238	SEAL, WATER PUMP	2		
3	26	67388	SEAL, FRONT	1		
4	22	32802	PIPE PLUG, DRAIN	1		
1		88014A 2	FRONT COVER ASSEMBLY	1		
2	26	89238	SEAL WATER PUMP	2		
3	26	67388	SEAL, FRONT	1		
4	22	32802	PIPE PLUG, DRAIN	1		
8	10	35386	SCREW, FRONT COVER TO CYL	5		
9	12	20084	WASHER, FRONT COVER TO CY	5		
8	10	35386	SCREW, FRONT COVER TO CYL	6		
9	12	20084	WASHER, FRONT COVER TO CYL	6		
10	27	68714	GASKET, FRONT COVER TO CYL	1		1
11	27	72099	GASKET, IMPELLER COVER TO F	1		1
11	27	88046	GASKET, IMPELLER COVER TO F	1		1
12	47	86462	IMPELLER, WATER PUMP	1		
13	12	91863	WASHER, IMPELLER SCREW	1		
14	13	21804	LOCKWASHER, IMPELLER SCRE	1		
15	10	59645	SCREW, IMPELLER ATTACHING	1		
16		71902	COVER, IMPELLER(L.H. ROTATI	1		
16		88013	COVER, IMPELLER(R.H. ROTATI	1		
17	10	67450	SCREW, COVER TO CYLINDER B	6		
18	10	35386	SCREW, IMPELLER COVER TO F	4		
19	12	20084	WASHER, COVER ATTACHING S	10		
20		71904	COVER, WATER INLET (L.H. ROT	1		
18	10	74824	SCREW, IMPELLER COVER TO F	5		
18	10	35386	SCREW, IMPELLER COVER TO F	4		
19	12	20084	WASHER, COVER ATTACHING S	15		
20		88012	COVER, WATER INLET (R.H. RO	1		
21		88045	TIMING MARKER (R.H. ROTATIO	1		
22	10	55714	SCREW, TIMING MARKER TO FR	2		
23	27	72098	GASKET, WATER INLET COVER	1		1
24	10	28668	SCREW, INLET COVER TO IMPEL	3		
25	12	21249	WASHER, INLET COVER SCREW	3		