



| Parts List | | | | | | |
|------------|-------|----------|-----------------------------|-----|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | 87 | 86080 | SWITCH, WATER TEMPERATUR | 1 | | |
| 2 | 13 | 26396 | LOCKWASHER, TEMPERATURE | 1 | | |
| 3 | 11 | 45076 | NUT, TEMPERATURE SWITCH (1 | 1 | | |
| 4 | 84 | 86044A 2 | WIRE ASSEMBLY, TAN/BLUE (3E | 1 | | |
| 5 | 87 | 88031 | SWITCH, OIL TEMPERATURE | 1 | | |
| 6 | 84 | 88032A 2 | WIRE ASSEMBLY, TAN/BLUE (2C | 1 | | |
| 7 | 84 | 86322A 8 | WIRE ASSEMBLY, BLACK (8") | 1 | | |
| 8 | | 86047A 1 | BUZZER HOUSING ASSEMBLY | 1 | | |
| 9 | | 86045 | TIMER, TEMPERATURE BUZZE | 1 | | |
| 10 | | 68878 | HORN | 1 | | |
| 11 | 10 | 69013 | SXREW, HORN ATTACHING | 2 | | |

