



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		85374A	DISTRIBUTOR ASSEMBLY, COM	1		
1		85374A	DISTRIBUTOR ASSEMBLY, COM	1		
2		62426	SCREEN, VENT - DISTRIBUTOR	2		
3	43	73579	GEAR, DRIVE - MAIN SHAFT(L.H)	1		
1	43	88189	GEAR, DRIVE - MAIN SHAFT(R.H)	1		
4	17	29077	ROLL PIN, DISTRIBUTOR GEAR	1		
5	26	72653	SEAL, HOUSING	1		
6		33653	FLET, BREAKER CAM LUBRICA	2		
7		72654	RETAINER, BREAKER CAM LUB	1		
8		33665	PLATE, MOUNTING - BREAKER	1		
9	10	23977	SCREW, MOUNTING PLATE TC	2		
-	12	62425	WASHER, BREAKER PLATE SL	2		
10		33662	CONDENSER	1		
11		48024	BRACKET, CONDENSER MOUN	1		
12	10	48021	SCREW, CONDENSER BRACKE	1		
13		34235	BREAKER ASSEMBLY, DISTRIBUTOR	1		
14	10	33650	SCREW, BREAKER ASSEMBLY	1		
15	25	33666	GROMMET, MOUNTING PLATE	1		
16		33658	LEAD, PRIMARY	1		
17		58217	ROTOR, DISTRIBUTOR	1		
18		33667	CAP, DISTRIBUTOR	1		
19	10	33660	SCREW, DISTRIBUTOR CAP	1		
20	10	33663	SCREW, DISTRIBUTOR CAP	1		
21	24	73642	SPRING, DISTRIBUTOR SHAFT	1		
22	53	73499	LOCK RING, DISTRIBUTOR SH	1		
23		73501	DRIVE SHAFT, DISTRIBUTOR	1		
24	27	34486	GASKET, DISTRIBUTOR	1		1
25	84	92151A	LEAD ASSEMBLY, HIGH TENSION	4		
26	33	75340	SPARK PLUG(CHAMPION#RBL-9	4		
27		54676	RETAINER, HIGH TENSION LEAD	1		
28	54	72821	CLAMP, HIGH TENSION LEADS	1		
29	16	73583	STUD, HIGH TENSION LEAD CLAI	1		
30	84	72825	WIRE, DISTRIBUTOR TO COIL	1		
31		32193A	COIL, IGNITION	1		
32		76354	BRACKET, IGNITION COIL MOUN	1		
33	10	66652	SCREW, MOUNTING BRACKET TI	1		
34	12	30164	WASHER, IGNITION COIL TERMIN	2		
34	13	26996	LOCKWASHER, IGNITION COIL T	2		
35	11	68219	NUT, IGNITION COIL TERMINAL	2		
36		67511	CLAMP UNIT, DISTRIBUTOR L.H.	1		
37	10	26385	SCREW, DISTRIBUTOR TO BLOC	1		