



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		72082A	ELBOW ASSEMBLY, EXHAUST	1		
2		72264A	BRACKET, SUPPORT - WATER	2		
3	10	37655	SCREW, SUPPORT BRACKET	4		
4	11	45812	NUT, SUPPORT BRACKET SCR	4		
5	10	35787	SCREW, EXHAUST ELBOW TO G	3		
6	13	35048	LOCKWASHER, EXHAUST ELBO\	3		
7		45586	SHUTTER, WATER - EXHAUST E	1		
8		70981	BELLOWS, EXHAUST ELBOW TC	1		
9	54	31765	CLAMP, BELLOWS ATTACHING (I	2		
9	54	33683	CLAMP, BELLOWS ATTACHING (C	2		

