



Parts List					
Ref	Class	Part	Description	Qty	Footnote
-	1376	5990A	CARBURETOR ASSEMBLY, COM	1	3.0
1		N.S.S.	AIR HORN (NOT SOLD SEPARA	1	
2		N.S.S.	POWER PISTON ASSEMBLY (R	1	
3			GASKET, AIR HORN	1	
4	10	33043	SCREW, AIR HORN TO FLOAT	7	
5	10	33048	SCREW, AIR HORN TO FLOAT	1	
6	13	26996	LOCKWASHER, AIR HORN SCF	8	
7	1397	3330	NUT, FUEL INLET - AIR HORN	1	
8	35	53336	FILTER, FUEL INLET - AIR HOR	1	
9	24	48143	SPRING, FUEL INLET - AIR HOF	1	
10			GASKET, FUEL INLET NUT (LAF	1	3.0
11			GASKET, FUEL INLET FILTER I	1	3.0
12	1397	5837	FLOAT ASSEMBLY	1	
13		N.S.S.	PIN, HINGE - FLOAT TO AIR HO	1	
14			CLIP, HINGE PIN	1	0
15			INLET NEEDLE AND SEAT ASS	1	0
16			GASKET, INLET NEEDLE AND S	1	3.0
17		N.S.S.	FLOAT BOWL ASSEMBLY (ROC	1	
18		N.S.S.	VENTURI CLUSTER ASSEMBLY,	1	
19			GASKET, VENTURI CLUSTER	1	3.0
20		N.S.S.	SCREW, VENTURI CLUSTER T	1	- ROCHESTER# 7009077
21			GASKET, VENTURI CLUSTER E	1	0
22		N.S.S.	SCREW, VENTURI CLUSTER T	2	- ROCHESTER# 7045762
23			GUIDE, PUMP DISCHARGE - FL	1	0
24			SPRING, PUMP DISCHARGE - F	1	0
25			BALL, PUMP DISCHARGE - FLO	1	0
26			POWER VALVE ASSEMBLY, FLI	1	0
27			GASKET, POWER VALVE	1	3.0
28	1397	6365	JET, FLOAT BOWL (STANDARC	2	
29	1397	2048	LEVER, PUMP - AIR HORN	1	
30	10	33047	SCREW, AIR HORN PUMP LEVI	1	
31		N.S.S.	PUMP SHAFT AND LEVER ASE	1	
32		N.S.S.	ROD, PUMP (ROCHESTER#70C	1	
33			CLIP, RETAINER - PUMP ROD	1	0
34			PUMP ASSEMBLY, FLOAT BOW	1	0
35			CLIP, RETAINER - FLOAT BOWL	1	0
36			SPRING, PUMP RETURN - FLI	1	0
37			GASKET, THROTTLE BODY	1	3.0
38		N.S.S.	THROTTLE BODY ASSEMBLY (	1	
39			IDLE ADJUSTING NEEDLE, THF	2	0
40	24	22050	SPRING, IDLE ADJUSTING NEE	2	