



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		90495A	PUMP ASSEMBLY (INCLUDES 16	1		
2	19	39924	CAP, POWER STEERING PUMF	1		
3		73873	PULLEY, POWER STEERING PI	1		
4	16	90511	STUD, PUMP TO BRACKET	1		
5		90510	BRACKET, POWER STEERING M	1		
6	16	54176	STUD, BRACKET TO HEAD	2		
7	12	55149	WASHER, POWER STEERING BF	2		
8	11	25269	NUT, POWER STEERING BRACK	2		
9	32	90494	HOSE, PRESSURE - POWER STE	1		
10	32	90327	HOSE, RETURN - POWER STEEF	1		
11	32	49533	HOSE, COOLER TO POWER STE	1		
12	54	35830	CLAMP, RETURN HOSE	1		
13	54	54428	CLAMP, HOSE ATTACHING	2		
14	10	90519	SCREW, BRACKET TO PUMP	1		
15	11	25269	NUT, PUMP TO BRACEKT STUD	1		
16	57	49043	V-BELT, POWER STEERING PUM	1		
17		60502	BRACKET, CYLINDER MOUNTIN	1		
18		63695	ADAPTOR PLATE, VALVE MOUN	1		
19	10	26065	SCREW, PLATE ATTACHING	3		
20	12	26825	WASHER, ATTACHING SCREW	6		
21	11	45592	NUT, ATTACHING SCREW	3		