



Parts List					
Ref	Class	Part	Description	Qty	Footnote
	50	97499A 2	STARTER MOTOR ASSEMBLY	1	
1		79206	HOUSING, DRIVE END	1	
2	23	33278	BUSHING, DRIVE AND HOUS	1	
3		33292	COLLAR, THRUST	1	
4	53	33290	RING, RETAINING - PINION ST	1	
5		33291	COLLAR, PINION STOP	1	
6		68609	DRIVE ASSEMBLY, CLUTCH	1	
7		79396	PLATE, BEARING	1	
8	23	71694	BUSHING, BEARING PLATE	1	
9	12	68614	WASHER, BEARING PLATE	1	
10	10	79209	SCREW, BEARING PLATE	2	
11		N. S. S.	ARMATURE, (DELCO REMY #1)	1	
12		N. S. S.	SHOE, POLE - FIELD COIL (DEL	4	
13		N. S. S.	SCREW, POLE SHOE TO FIELD	4	
14		N. S. S.	INSULATION, FIELD COIL DELC	1	
15	25	79208	GROMMET, FIELD COIL - FIELD	1	
16		79212	FIELD COIL ASSEMBLY	1	
17	12	68613	WASHER, LEATHER - COMMU	1	
18		79211	FRAME, COMMUTATOR END - I	1	
19		N. S. S.	BOLT, THRU (DELCO REMY #1	2	
20		33284	HOLDER, INSULATED - FIELD F	2	
21		33283	HOLDER, FIELD FRAME BRUSH	2	
22		33270	BRUSH, FIELD FRAME	4	
23		N. S. S.	SCREWE, BRUSH LEAD (DELCO	2	
24		N. S. S.	SCREW, BRUSH LEAD (DELCO	2	
25	24	33285	SPRING, FIELD FRAME BRUSH	4	
26		N. S. S.	PIN, DOWEL - FIELD FRAME (D	1	
27		33297	LEVER, SHIFT	1	
28	16	48268	STUD, SHIFT LEVER TO DRIVE	1	
29	12	68615	WASHER, SHIFT LEVER STUD	1	
30	11	26484	NUT, SHIFT LEVER STUD	1	
31		N. S. S.	PLUNGER, SHIFT LEVER (DELCO	1	
32	17	79207	PIN, PLUNGER TO SHIFT LEVE	1	
33		N. S. S.	SPRING, PLUNGER RETURN (E	1	
34		N. S. S.	SCREWE, SOLENOID SWITCH	2	
35		13037	SOLENOID SWITCH ASSEMBLY	1	