



1686

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		864289T	SHIFT ACTUATOR, Shift	1		
2		862909	BRACKET, Shift Plate	1		
3		864616	RETAINER, Shift Cable	1		
4	23	98828	SPACER	1		
5	18	32857	COTTER PIN	1		
6	23	863133	SPACER, Actuator	1		
7		863134	LEVER, Shift Arm	1		
8	23	863132	SPACER, Shift Arm	1		
9	10	40011151	SCREW, (M8 x 35)	1		
10	16	864361	STUD	1		
11	16	96112	STUD, (.250-28 x 2.00), Throttle Ca	1		
12	11	13438	NUT, (.250-28)	3		
13	11	46335	NUT, (.375-24)	1		
14	12	35462	WASHER, (.2656 x .625 x .0625)	5		
15	12	34931	WASHER, (.406 x .734 x .063) Stai	2		
16	10	40011155	SCREW, (M8 x 55)	1		
17	87	814281A	SWITCH	1		
18	10	865076	SCREW, (6-32 x 1.25)	2		
19	23	864386	SPACER, Switch	1		