



13827

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	50	864340A 2	STARTER ASSEMBLY	1		
2	10	861788	SCREW, (M10 x 1.5), Special	2		
3	11	806949	NUT, (M8-1.5)	1		
4	13	40024 7	LOCKWASHER, (M8)	1		
5	11	40021 1	NUT, (M5)	1		
6	13	26996	LOCKWASHER, (#10)	1		
7	88	79023A91	FUSE ASSEMBLY, 90 Ampere	1		
8	11	826711 9	NUT, (.250-28)	1		
9	85	79695	BOOT, Insulator - Black	1		
10		863077I	ALTERNATOR ASSEMBLY, Black	1		
11	10	824459110	SCREW, (M8 x 110)	1		
12	11	40136 8	NUT, (M8)	1		
13		865594T01	BRACKET, Alternator	1		
14	10	40108120	SCREW, (M10 x 120)	1		
15	10	885526 60	SCREW, (M8 x 60)	1		
16	10	40108 35	SCREW, (M10 x 35)	1		
17	11	40021 2	NUT, (M6)	2		
18	57	865635001	BELT, Serpentine	1		