



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	46	862914A 2	PUMP, Sea Water, Complete	1		
2	47	862232A 2	IMPELLER	1		
3	25	841807	O-RING, (3.500 x .103)	1		
4	26	862037	SEAL, Oil	1		
5		862235A 1	DRIVESHAFT ASSEMBLY, Impe	1		
6		862039	TOLERANCE RING	1		
7	26	862040	SEAL, Lip	1		
8	22	806608A 1	PLUG KIT, Blue	2		
9	25	32509	O-RING, (.489 x .070)	2		2,3
10		881879A 6	SENSOR, (0 - 100 PSI), Water Pr	1		
11	10	40003 28	SCREW, (M6 x 16)	4		
12	10	40003 33	SCREW, (M6 x 40)	2		
13		863859T	BRACKET, Sea Water Pump	1		
14	10	40003 31	SCREW, (M6 x 30)	1		
15		862351T	PULLEY	1		
16		863861T	BRACKET, Idler Pulley	1		
17		865444T	PULLEY, (3.50 Inch Diameter), Idle	1	Grooved	
18		818382	PULLEY, Idler	1	Non-Grooved	
19	10	40108 16	SCREW, (M10 x 16 Hex Flange)	2		
20	10	40108 45	SCREW, (M10 x 45)	1		
21	16	854309	STUD, (M10 x 76)	2		
22	11	826292	NUT, (M10)	2		