



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		805222A	DISTRIBUTOR ASSEMBLY	1		
2		808483	CAP	1		
3	10	808491	SCREW	2		
4		808484	ROTOR	1		
5		808485	SHAFT AND MAGNET	1		
6		808487	RETAINER	1		
7		808486	SHIELD	1		
8		811639	COIL	1		
9		811637	MODULE	1		
10	10	811638	SCREW	2		
11		811641	POLE PIECE	1		
12	17	808488	PIN	1		
13	12	46350	WASHER	1		
14	12	808489	WASHER	1		
15	43	808490	DRIVE GEAR	1		
16	17	34109	PIN	1		
17	84	817376T	HARNESS-DISTRIBUTOR MODU	1		
18		806673T	COIL-IGNITION	1		
19	10	86750	SCREW (5/16-18 X 5/8 IN.)	2		
20	12	20084	WASHER	2		
21	16	90096A	1 STUD ASSEMBLY	2		
22	54	72821	RETAINER	2		
23		54676	RETAINER (2 WIRE)	2		
24		32783	RETAINER (3 WIRE)	2		
25		32784	RETAINER (4 WIRE)	2		
26	84	816608A70	CABLE KIT-IGNITION (SPARK PLL	1		
27		52185	CLAMP	1		
28	10	805559	SCREW (3/8-16 X 3/4 IN.)	1		
29	27	34486	3 GASKET-DISTRIBUTOR	1		2
30	33	816336	SPARK PLUG	8		
-	27	861246A98	GASKET SET-ENGINE OVERHAU	1		