



2556

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		93911A 4	HOUSING ASSEMBLY, Flywheel	1		
2	22	74036	FITTING, Grease	1		
3	10	47651	SCREW, (.437-14 x 1.50)	6		
4		93918A 1	SHIELD ASSEMBLY, Lower	1		
5	10	96995	SCREW, (.375-16 x .880)	3		
6		93919A 1	SHIELD ASSEMBLY, Upper	2		
7	11	826709 12	NUT, (.375-16)	8		
8	10	96995	SCREW, (.375-16 x .880)	8		
9		93923A 1	MOUNT ASSEMBLY, Flywheel Ho	2		
10		814263A 1	BASE ASSEMBLY, Mount Assembl	2		
11	11	816331	NUT, (.750-16), Jam	1		
12	14	12657	TAB WASHER, Tab	1		
13	11	859126	NUT, (.750-16)	1		
14		93906A 2	SHAFT, Output	1		
15	25	29845	O-RING, (.924 x .103)	2		
16	53	94104	RING, Retaining	1		
17	30	62780T	BEARING, Ball	1		
18	53	841897T	RING, Retaining	1		
19	10	47651	SCREW, (.437-14 x 1.50)	4		
20	13	32993	LOCKWASHER, (.437)	4		
21		814309A 1	HOUSING ASSEMBLY	1		
22	19	12304	PLUG, Timing Window	1		
23	23	49126	BUSHING, Pilot	1		
24	10	37612	SCREW, (.375-16 x 1.250)	1		
24	10	34353	SCREW, (.375-16 x 1.00)	1		
24	10	47688	SCREW, (.375-16 x 2.750)	2		
25	13	35048	LOCKWASHER, (.375)	4		
26		93920 1	PLATE, Cover	1		
27	10	92913	SCREW, (.437-14 x .750)	2		
28	13	32993	LOCKWASHER, (.437)	2		
29		818718A 3	COVER KIT, Flywheel Insectio	1		
30	27	86015	GASKET, Flywheel Inspection Cov	1		
31	10	98253	SCREW, (.250-20 x .500)	7		
32	13	26992	LOCKWASHER, (.250)	7		
33		817416A 4	HOUSING ASSEMBLY, Bearing	1		
34	30	93944A 2	BEARING SET, Ball (Includes Pa	1		
35	23	817417T	SPACER	1		
36	30	93944A 2	BEARING SET, Ball (Includes Pa	1		
37	53	93914	RING, Retaining	1		
38	53	93915	RING, Retaining	1		
39	26	93924	SEAL, Oil	1		