



A = To Transom

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	32	863489	HOSE, Power Steering Cooler To C	1		
2	21	864206A	CHECK VALVE ASSEMBLY	1		
3	32	863623	HOSE, Check Valve To Fuel Coole	1		
4		863455	FITTING, Y	1		1
5	32	862274	HOSE, Lower Circulation Pump	1		1
6	32	863453	HOSE, Y Fitting To Circulating Pum	1		1
7	32	863458	HOSE, Thermostat Housing To Por	1		1
8	32	863459	HOSE, Thermostat Housing To Sta	1		
9	32	807661	HOSE, Transom To Power Steering	1		1
10	32	863670	HOSE, Fuel Cooler To Water Distrib	1	(With Power Steering)	1
10	32	863937	HOSE, Fuel Cooler To Water Distrib	1	(With Out Power Steering)	1
11	22	863760	FITTING, Lower Distribution	1		1
12	25	62702	O-RING, (.301 x .070)	2		
13	32	863490	HOSE, Water Drain Accumulator To	1		1
14	32	863491	HOSE, Distribution Fitting To "Y" Fi	1		1
15	32	42850	HOSE, (.44.00 Inches Bulk), Starbo.	1	(Cut To 22.00 Inch Length)	1
16	32	864258	HOSE, Port Manifold To Distributor	1		1
17	32	862317	HOSE, Cylinder Block Drain To Dist	2	(Port-23 Inch) (Starboard-17.00 Inc	1
18	22	862225	FITTING, Pushlock	4		1
19	32	863465	HOSE, Drain Accumulator To Tee f	1		1
20	22	863464	FITTING, Tee	1	(Bravo Only)	
20	22	863464A	FITTING	1	(Alpha Only)	1
NS	23	864327	BUSHING, Orifice	1	(Alpha Only)	1
NS	25	864353	O-RING	1	(Alpha Only)	1
21	25	62702	O-RING, (.301 x .070)	2		
22	32	863496	HOSE, T Fitting To Port Elbow	1		1
23	32	863828	HOSE, T Fitting To Starboard Elbow	1		
24	54	815504212	CLAMP, Worm Gear, Hose	2		
25	54	815504216	CLAMP, Worm Gear, Hose	AR		
26	54	815504222	CLAMP, Worm Gear, Hose	2		
27	54	815504228	CLAMP, Worm Gear, Hose	1		
28	54	815504232	CLAMP, Worm Gear, Hose	AR		
29	22	862603	FITTING, Male Quick Connector (T	2		
30	32	863611	HOSE, Sea Water Pump To Power	1		1
31	32	863343	HOSE, Sea Water Pump To Water	1		
32		863841T	WATER TUBE, Brass	1	(Compact Hydraulic Steering)	