



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		805185A 2	DISTRIBUTOR	1		
2		805759A 2	CAP	1		
3	27	805760	GASKET	1		
4	10	90926	SCREW	4		
5		13524A 1	ROTOR/SENSOR WHEEL	1		
6	87	91019A 6	SENSOR ASSEMBLY	1		
7	10	66686	SCREW	1	(1 IN.)	
7	10	72202	SCREW	1	(1-1/4 IN.)	
8	43	818807	DRIVE GEAR	1		
9	17	47617	PIN	1		
10	23	90915	BUSHING	2		
11	12	90931	WASHER	1		
12	27	34486 3	GASKET	1		5
13		52185	CLAMP	1		
14	10	806681	SCREW	1		
15	13	26996	LOCKWASHER	2		
16	11	68219	NUT	2		
17	84	816761A17	SPARK PLUG WIRE KIT	1		
18	85	63709A 1	BOOT ASSEMBLY	8		
19	33	59571	SPARK PLUG	8		
20		54676	RETAINER	2	(2 WIRE)	
21		32783	RETAINER	2	(3 WIRE)	
22		32784	RETAINER	2	(4 WIRE)	
23	392	805570A 2	IGNITION COIL	1		
24		65970T 1	BRACKET	1		
25	10	41408	SCREW (1-1/2")	1		
26	13	26996	LOCKWASHER	2		
27	11	68219	NUT	2		
28	10	98261	SCREW (3/4")	1		
29	16	90096A 1	STUD ASSEMBLY	2		
30	54	72821	RETAINER	2		
-	27	806871A96	GASKET SET-OVERHAUL	1	CONTENTS INDICATED BY FOO 11	