



| Parts List | | | | | | |
|------------|-------|-----------|----------------------------|-----|----------------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | 50 | 806964A 3 | STARTER MOTOR ASSEMBLY | 1 | (SEE "STARTER MOTOR" FOR | |
| 2 | 10 | 805343 2 | SCREW (3/8-16 X 4-3/8 IN.) | 2 | | |
| 3 | 11 | 806949 | NUT (M8-1.5) | 1 | | |
| 4 | 11 | 40021 1 | NUT (M5-0.8) | 1 | | |
| 5 | 13 | 26996 | LOCKWASHER (#10) | 1 | | |
| 6 | 85 | 79695 | BOOT-INSULATOR | 1 | | |
| 7 | | 807652T | ALTERNATOR ASSEMBLY | 1 | (SEE "ALTERNATOR" FOR BRE/ | |
| 8 | 12 | 96457 | WASHER-PHENOLIC | 1 | | |
| 9 | 13 | 26996 | LOCKWASHER (#10) | 1 | | |
| 10 | 11 | 79989 | NUT (#10-24) | 1 | | |
| 11 | 13 | 26992 | LOCKWASHER (1/4 IN.) | 1 | | |
| 12 | 11 | 94330 | NUT (1/4-20) | 1 | | |
| 13 | | 807750T | BRACE | 1 | | |
| 14 | 10 | 98261 | SCREW (3/8-16 X 3/4 IN.) | 1 | | |
| 15 | 13 | 35048 | LOCKWASHER (3/8 IN.) | 1 | | |
| 16 | 10 | 29198 | SCREW AND LOCKWASHER (5/1 | 1 | | |
| 17 | | 860370T | BRACKET-ALTERNATOR/POWER | 1 | | |
| 18 | 16 | 860102 | STUD | 3 | | |
| 19 | 10 | 56743 | SCREW (3/8-24 X 3-1/8 IN.) | 1 | | |
| 20 | 11 | 23161 | NUT (3/8-24) | 1 | | |
| 21 | | 807767T | BRACKET-IDLER | 1 | | |
| 22 | 10 | 98261 | SCREW (3/8-16 X 3/4 IN.) | 1 | | |
| 23 | 11 | 29250 | NUT (5/16-24) | 1 | | |
| 24 | 43 | 818381 2 | PINION STUD | 1 | | |
| 25 | | 818380T | BUSHING | 1 | | |
| 26 | | 807757T | PULLEY | 1 | | |
| 27 | 11 | 817618 | NUT (7/16-20) | 1 | | |