



Parts List							
Ref	Class	Part	Description	Qty	Comment	Footnote	
1	46	72774A50	WATER PUMP ASSEMBLY	1			
2	46	807151A14	BODY/IMPELLER KIT	1			
3		87631A 4	COVER	1			
4	10	73275	SCREW (2-7/8")	2			
4	10	99347	SCREW (3-3/4")	3			
5	12	20084	WASHER	5			
6	27	805215 1	GASKET	1			
7		94916	OUTER WEAR PLATE	1			
8	27	94914	GASKET	2			
9	19	59504	PLUG	1			
10	47	59362 1	IMPELLER	1			
11	28	56662	KEY (USE WHERE APPLICABLE)	1			
12		94576	INNER WEAR PLATE	1			
13	25	94288	QUAD RING	1			
14	46	94913A 2	PUMP HOUSING ASSEMBLY	1			
15	26	90562	OIL SEAL	2			
16	30	72961	BALL BEARING	2			
17		59501A 1	SHAFT	1			
18	53	23720	SNAP RING	1			
19	26	72785	OIL SEAL	1			
20		47530	HUB	1			
21		52822T	PULLEY	1			
22	10	47277	SCREW (3/4")	4			
23	13	39107	LOCKWASHER	4			
24	13	39107	LOCKWASHER	3			
25	11	21908	NUT	3			
26		89535T 1	BRACKET	1			
27	10	34353	SCREW (1")	2			
28	13	35048	LOCKWASHER	2			
29	12	34714	WASHER	1			
30		89609 1	BRACE	1			
31	10	34353	SCREW (1")	1			
32	13	35048	LOCKWASHER	1			
33	12	34714	WASHER	1			
34	10	35786	SCREW (1")	1			
35	13	35048	LOCKWASHER	1			
36	11	46335	NUT	1			
37	22	32802	PLUG (FOR WATER PUMP BODY)	1			
38	57	13457T	BELT	1			