



1915

Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		860256A 4	HOUSING ASSEMBLY-THERMOSTAT	1	
2	22	32803	PLUG-PIPE (3/8 IN.)	2	
3	27	806871	GASKET-THERMOSTAT	1	3
4	27	53045 1	GASKET	1	3
5		807252T 2	THERMOSTAT (160 DEG.)	1	
6	23	806922	SLEEVE	1	
7	10	47688	SCREW (3/8-16 X 2-3/4 IN.)	2	
8	13	35048	LOCKWASHER (3/8 IN.)	2	
9	32	808033	HOSE-THERMOSTAT HOUSING	1	
10	32	808045	HOSE-HOSE EXTENDER TO TRA	1	
11	32	808044 1	HOSE-OIL COOLER TO SEA WAT	1	
12	32	17435 79	HOSE-SEA WATER PUMP TO DR	1	
13	54	815504222	CLAMP-HOSE	7	
14	32	87108	HOSE-THERMOSTAT HOUSING	1	(Use Without Drain Fitting)
14	32	861590A 2	HOSE-THERMOSTAT HOUSING	1	(Use With Drain Screw)
15	54	815504232	CLAMP	2	
16	32	806635 1	HOSE-THERMOSTAT HOUSING	1	
17	32	807697	HOSE-THERMOSTAT HOUSING	1	
18	54	815504220	CLAMP-HOSE	4	
19	54	47715	CLIP	1	
20	11	29250	NUT (5/16-24)	1	
21		860315A 1	EXTENDER-HOSE	1	
22	22	806608A 1	PLUG-DRAIN	2	
23	25	62706	O-RING	2	
24		860418T	BRACKET	1	
25		860417T	CLAMP	1	
26	12	35462	WASHER	1	
27	11	826708 8	NUT	1	
28	22	46982	FITTING-90 DEGREES	1	
29	22	806608A 1	PLUG-Drain Fitting	1	
30	25	32509	O-RING	1	
31	22	860088	FITTING	1	
NS	19	807992 3	COVER-HOSE CLAMP END	AR	2
-	27	861246A98	GASKET SET-ENGINE OVERHAU	1	