



1908

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	32	808045	HOSE, Transmission Cooler to Hose	1		
2	32	808033	HOSE, Molded, Hose Extender to T	1		
3	32	861590A	2 HOSE ASSEMBLY, Thermostat Ho	1		
4	32	17435 79	HOSE, (.96.00 Inches Bulk), Sea W'	1		
5	32	864977	HOSE, Thermostat Housing to Elbo	1		
5	32	864705	HOSE, Thermostat Housing to Elbo	1	[V-Drive]	
6	32	864979	HOSE, Thermostat Housing to Elbo	1		
6	32	863813	HOSE, Thermostat Housing to Elbo	1	[V-Drive]	
7	32	807697	HOSE, Thermostat Housing to Low	1		
8	32	806635	1 HOSE, Thermostat Housing to Low	1		
9	32	808044	1 HOSE, Molded, Sea Water Pump to	1		
10		860315A	1 TUBE, Hose Extender	1		
11		860418T	BRACKET, Hose Extender	1		
12		860417T	CLAMP, Hose Extender Bracket	1		
13	12	35462	WASHER, (.2656 x .625 x .0625)	1		
14	11	826708	8 NUT, (.250-20)	1		
15	22	806926A	1 ELBOW KIT, Drain	2		
16	22	806608A	1 PLUG KIT, Blue, Fitting	4		
17	25	62706	4 O-RING, (.426 x .070)	4		
18	22	860088	BUSHING	1		
19	22	46982	FITTING, (90 Degree)	1		
20	54	815504216	CLAMP, Worm Gear, Hose	AR		
21	54	815504222	CLAMP, Worm Gear, Hose	2		
22	54	815504228	CLAMP, Worm Gear, Hose	1		
23	22	863804	FITTING, (.750-14), Barb	2		
NS	19	807992	3 COVER, Hose Clamp End	AR		