



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-	50	12177A 2	STARTER MOTOR (L.H. ROTATI	1		
-	50	79604A 3	STARTER MOTOR (R.H. ROTATI	1		
1		75666	HOUSING (L.H. ROTATION)	1		9
1		13754	HOUSING (L.H. ROTATION)	1		6,5
1		79206	HOUSING (R.H. ROTATION)	1		
2	23	33369	BUSHING	1		
3		814474	COLLAR	1		
4	53	33290	RING	1		
5		33291	COLLAR	1		
6		79205	DRIVE (L.H. ROTATION)	1		
6		68609	DRIVE (R.H. ROTATION)	1		
7		79396	BEARING PLATE	1		
8	23	71694	BUSHING	1		
9	12	68614	WASHER	1		
10		N.S.S.	SCREW (DELCO REMY #19727)	2	L.H. ROTATION	5
11		71693	ARMATURE	1	L.H. ROTATION	5
12		N.S.S.	POLE SHOE (DELCO REMY #1E	4	L.H. ROTATION	5
10		N.S.S.	SCREW (DELCO REMY #19840)	2	L.H. ROTATION	6
11		75665	ARMATURE	1	L.H. ROTATION	6
12		N.S.S.	POLE SHOE (DELCO REMY #81	4	L.H. ROTATION	6
10	10	75659	SCREW (DELCO REMY #18939)	2	R.H. ROTATION	
11		68607	ARMATURE	1	R.H. ROTATION	
12		N.S.S.	POLE SHOE (DELCO REMY #81	4	R.H. ROTATION	
13		N.S.S.	SCREW (DELCO REMY #96839)	4		
14	25	79208	GROMMET (L.H. ROTATION)	1		
14		N.S.S.	GROMMET (D/R #1846097) (R.)	1		
15		79212	FIELD COIL ASSEMBLY L.H. RC	1		5,9
15		75664	FIELD COIL ASSEMBLY L.H. RC	1		6
15		75664	FIELD COIL ASSEMBLY (R.H. RI	1		
16	12	33258	WASHER	1		
17		79211	COMMUTATOR END FRAME	1		
18		N.S.S.	BOLT (DELCO REMY #1941111)	1		
18		N.S.S.	BOLT (DELCO REMY #1939970)	1		
19		33284	HOLDER	2		
20		33283	HOLDER	2		
21		33270	BRUSH	4		
22		N.S.S.	SCREW (DELCO REMY #19677)	2		
22		N.S.S.	SCREW (DELCO REMY #44352)	2		
23		33294	SUPPORT PACKAGE	2		
24	24	33285	SPRING	4		
25		N.S.S.	POW/EL RM (DELCO REMY #1E	1		