



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		805597T	BRACKET (REAR) (L.H. ROTATIO	2		
1		66417T	BRACKET (REAR) (R.H. ROTATIO	2		
1		37269	SCREW (2")	4		
2	10			4		
3	13	32993	LOCKWASHER	4		
4	10	57357	SCREW (2-1/4")	2		
5	13	32993	LOCKWASHER	2		
6	11	29553	NUT	2		
7		71128A	BRACKET (FRONT)	2		
8	10	68101	SCREW (1-3/8")	5		
8	10	34354	SCREW (1-1/2")	1		
9	13	35048	LOCKWASHER	6		
10	10	57357	SCREW	2		
11	13	32993	LOCKWASHER	2		
12	11	29553	NUT	2		
13		66166A	TRUNNION	4		
14	13	68102	LOCKWASHER	4		
15		66284A	BASE ASSEMBLY ENGINE	2		
16	11	20739	JAM NUT ENGINE	2		
17	14	66658	TAB WASHER ENGINE	2		
18		816326A	BASE ASSEMBLY TRANSMISSIC	2		
19	11	816331	NUT TRANSMISSION	2		
20	14	66658	TAB WASHER TRANSMISSIO	2		
21	11	20739	JAM NUT	4		