



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	84	12307A	HARNESS (WITH BREAKER POIN	1		
1	84	12307A	HARNESS (WITH THUNDERBOL	1		
2		97257A	1 WATER TEMPERATURE SENDEI	1		
2		97258A	1 WATER TEMPERATURE SENDEI	1		
2		49734A	1 WATER TEMPERATURE SENDEI	OPT.		
3	13	26996	LOCKWASHER	1		
4	11	68219	NUT	1		
5		815425	OIL PRESSURE SENDER	1		
5		37293	OIL PRESSURE SENDER (DUAL)	OPT.		
6	13	26996	LOCKWASHER	1		
7	11	68219	NUT	1		
8	22	805328	1 ELBOW	1		
9	22	42554	NIPPLE	1		
10		41170T	BRACKET	1		
11	10	37612	SCREW	1		
12	13	35048	LOCKWASHER	1		
13	10	35787	BOLT	1		
14	23	15895	SPACER (1-1/2")	AR		
14	23	91034	SPACER (1/2")	AR		
16	13	35048	LOCKWASHER	1		
18	88	11178	CIRCUIT BREAKER (50 AMP.)	1		
19	13	26996	LOCKWASHER	2		
20	11	68219	NUT	2		
21	10	45862	SCREW	2		
22	10	22028	SCREW	1		
23	12	56681	WASHER	3		
24	11	61356	NUT	2		
25	85	96819T	INSULATOR	1		
26	89	96054	STARTER SOLENOID	1		
27	10	47910	SCREW	2		
28	11	20088	NUT	2		
29	13	26992	LOCKWASHER	2		
30	11	26419	NUT (8-32)	2		
31	11	94330	NUT (1/4-20)	2		
32		821125A	1 IGNITION MODULE	1	IGNITION MODULE MOUNTED O	
33	84	15275A	1 HARNESS	1	IGNITION MODULE MOUNTED O	
34	10	76630	SCREW	3	IGNITION MODULE MOUNTED O	
35	13	26992	LOCKWASHER	3	IGNITION MODULE MOUNTED O	
36	23	92152	SPACER	3	IGNITION MODULE MOUNTED O	
37		805361T	6 IGNITION MODULE	1	IGNITION MODULE MOUNTED C	
38	84	805362A	2 HARNESS	1	IGNITION MODULE MOUNTED C	