



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	50	806964A 3	STARTER MOTOR ASSEMBLY	1	(SEE "STARTER MOTOR" FOR E	
2	10	805343 2	SCREW (3/8-16 X 4-3/8 IN.)	2		
3	11	806949	NUT (M8-1.5)	1		
4	11	40021 1	NUT (M5-0.8)	1		
5	13	26996	LOCKWASHER (#10)	1		
6	85	79695	BOOT-INSULATOR	1		
7		807652T	ALTERNATOR ASSEMBLY	1	(SEE "ALTERNATOR" FOR BRE/	
8	12	96457	WASHER-PHENOLIC	1		
9	13	26996	LOCKWASHER (#10)	1		
10	11	79989	NUT (#10-24)	1		
11	13	26992	LOCKWASHER (1/4 IN.)	1		
12	11	94330	NUT (1/4-20)	1		
13		807750T	BRACE	1		
14	10	98261	SCREW (3/8-16 X 3/4 IN.)	1		
15	13	35048	LOCKWASHER (3/8 IN.)	1		
16	10	29198	SCREW AND LOCKWASHER (5/1	1		
17		860370T 1	BRACKET-ALTERNATOR	1		
18	16	860102	STUD	3		
19	10	56743	SCREW (3/8-24 X 3-1/8 IN.)	1		
20	11	23161	NUT (3/8-24)	1		
21		807767T	BRACKET-IDLER ADJUSTMENT	1		
22	10	98261	SCREW (3/8-16 X 3/4 IN.)	1		
23	11	29250	NUT (5/16-24)	1		
24	43	818381 2	PINION STUD	1		
25		818380T	BUSHING	2		
26		807757T	PULLEY	2		
27	11	817618	NUT (7/16-20)	2		
28		807753T	BRACKET-IDLER	1		
29	11	32219	NUT (3/8-16)	3		
30	10	816601	SCREW (7/16-20 X 1-1/2 IN.)	1		