



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		26079A	2 PLATE KIT	1		
2	10	15001	SCREW (#8-16 X 7/8 IN.)	4		
3		805383T	BRACKET-HARNESS MOUNTING	1		
4	22	805328	1 ELBOW-90 DEG. (1/8 IN.)	1		
5		815425	SENDER-OIL PRESSURE	1		
5		37293	SENDER-OIL PRESSURE (DUAL : OPT	1		4
6		97257A	1 SENDER-WATER TEMPERATUR	1		
6		49734A	1 SENDER-WATER TEMPERATUR	OPT		4
7	13	26996	LOCKWASHER (#10)	2		
8	11	68219	NUT (#10-32)	2		
9	22	805059	BUSHING-REDUCER	1	AUDIO WARNING SYSTEM	
10	87	805605A	1 SWITCH-OIL PRESSURE	1	AUDIO WARNING SYSTEM	
11		816492A	6 ALARM KIT	1	AUDIO WARNING SYSTEM	
12	84	95084A	9 CABLE ASSEMBLY	1	BRAVO ENGINES	
13	88	79091	FUSE (20 AMP)	1	BRAVO ENGINES	
14	84	95084A10	CABLE ASSEMBLY	1	BRAVO ENGINES	
15		805592A	1 CONNECTOR	1	BRAVO ENGINES	
16		806612T	SENSOR-KNOCK	1		
17		805218T	SENSOR-COOLANT TEMPERATL	1		
18	22	806705	1 FITTING-Y	1		