



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		860256A 1	HOUSING ASSEMBLY-THERMOSTAT	1	(5.7L/LX ALPHA)	
2	22	32803	PLUG-PIPE (3/8 IN.)	2		
3	27	806871	GASKET-THERMOSTAT	1		2
4	27	53045 1	GASKET	1		2
5		807252 2	THERMOSTAT (160 DEG.)	1		
6	23	806922	SLEEVE	1		
7	10	98508	SCREW (3/8-16 X 3 IN.)	2		
8	32	808033	HOSE-THERMOSTAT HOUSING	1		
9	32	860089	HOSE-FUEL COOLER TO POWER	1		
10	32	807661	HOSE-POWER STEERING COOL	1		
11	54	815504222	CLAMP-HOSE	5		
12	54	815504212	CLAMP-HOSE	1		
13	32	87108	HOSE-THERMOSTAT HOUSING	1		
14	54	815504232	CLAMP	2		
15	32	860144	HOSE	1	THERMOSTAT HOUSING TO PC	
16	32	807697	HOSE	1	THERMOSTAT HOUSING TO ST	
17	54	815504220	CLAMP-HOSE	4		
18	54	47715	CLIP	1		
19	11	29250	NUT (5/16-24)	1		
20		12552	LIFTING EYE	1	(5.7L/LX ALPHA)	
21		807292T	COOLER-POWER STEERING OIL	1		
22		805546A 2	BRACKET-TRANSMISSION OIL C	1		
23		77223 3	PAD	1		
24	54	815504224	CLAMP	1		
25	10	816585	SCREW (5/16-18 X 7/8 IN.)	1		
-	27	806871A96	GASKET SET-OVERHAUL	1	?27-806871A96!	