



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		860100A 2	MANIFOLD-INTAKE	1		
2	10	808010	BOLT (5/16-18 X 1-3/8 IN.)	8		
3	22	860075	PLUG-PIPE (1/2 IN.)	3		
4	32	861213	TUBE-EXHAUST	1		
5	22	805563	FITTING	2		
6	22	48358	PLUG-INTAKE (3/8 IN.)	1		
7	54	73668	J-CLIP	2		
8	10	86750	J-SCREW (5/16-18 X 5/8 IN.)	2		
9	27	807473A 1	GASKET SET-INTAKE MANIFOLD	1		2
10		850399	PUMP ASSEMBLY-WATER	1		
11	27	34897	GASKET-WATER PUMP	2		2
12	10	32132	SCREW (3/8-16 X 1-3/4 IN.)	1		
12	10	47688	SCREW (3/8-16 X 2-3/4 IN.)	1		
12	16	35342	STUD	2		
13		807729T	PULLEY-WATER PUMP	1		
14	10	47277	SCREW (5/16-24 X 3/4 IN.)	4		
15		852946	HARMONIC BALANCER	1		
16		807730T	PULLEY-CRANKSHAFT	1		
17	57	807755 2	BELT-SERPENTINE	1	(STANDARD COOLING) (ALPHA	
17	57	807755 1	BELT-SERPENTINE	1	(STANDARD COOLING) (BRAVO	
17	57	807755 3	BELT-SERPENTINE	1	(CLOSED COOLING)	
18	10	32515	BOLT (7/16-20 X 2-1/2 IN.)	1		
19	13	39131	LOCKWASHER	1		
20	12	35332	WASHER	1		
21	10	34352	BOLT (3/8-24 X 7/8 IN.)	3		
22		835005	TIMING COVER ASSEMBLY	1	(SCREWS-GROMMETS-OIL SEAL	
23		53338	VALVE-FILTER	1	W/O REMOTE OIL FILTER	
24	10	54786	SCREW (5/16-18 X 1-1/4 IN.)	2	W/O REMOTE OIL FILTER	
25		14957	FILTER-OIL	1	W/O REMOTE OIL FILTER	
26		852940	RETAINER-OIL SEAL (REAR)	1		
27	27	14241	GASKET	1		2
28	26	852941	SEAL-OIL (REAR)	1		2
29	10	14243	BOLT (1/4-20 X 1-3/4 IN.)	1		
30	10	14242	BOLT (1/4-20 X 7/8 IN.)	2		
31	17	14263	PIN-DOWEL	1		
32	11	816730	NUT (1/4-20)	1		
33	16	14827	STUD	1		
-	27	861246A98	GASKET SET-ENGINE OVERHAU	1		