



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		809995	COVER-ROCKER	1	(W/O OIL FILL HOLE)	4
1		809996	ROCKER COVER	1	(W/O OIL FILL HOLE)	4
2	36	18710 1	CAP-OIL FILL	1		4
3	10	17344	SCREW	8		4
4	27	17467	GASKET-ROCKER COVER	2		2,4
5	25	52188	GROMMET	2		
6		97850	ELBOW (90 DEG.)	1		
7	32	861977 63	HOSE-PCV	1		
8	21	861476	VALVE-PCV	1		
9	32	15894 24	HOSE-BREATHER	1		
10	54	815504105	CLAMP	2		
11		807688T	TUBE-OIL FILL	1		
12		17339 1	PUSH ROD	16		4
13		824317 1	VALVE-EXHAUST	8	(STANDARD)	4
13		824318 1	VALVE-EXHAUST	AR	(.030 O.S.)	
14		802555	VALVE-INTAKE (STANDARD)	8	(5.0L)	4
14		809992	VALVE-INTAKE (STANDARD)	8	(5.7L)	4
15	26	97664 1	SEAL-VALVE (INTAKE)	8		2,4
15	26	804507	SEAL-VALVE (EXHAUST)	8		1,2,4
16	24	48347 1	SPRING	16		4
17		48348 1	CAP	16		4
18	28	54797 1	KEY	32		4
19		35329	ARM KIT-ROCKER	16		4
20		35331	BALL UNIT	16		4
21	11	34516	NUT	16		4
22	938	802556	HEAD ASSEMBLY-CYLINDER	2	(5.0L)	4
22	938	803860T	HEAD ASSEMBLY-CYLINDER	2	(5.7L)	4
23	16	34522	STUD (.003 O.S.)	AR		
23	16	34521	STUD (.013 O.S.)	AR		
24	27	75611	GASKET	2		2,4
25	10	11968	BOLT (7/16-14 X 1-3/4 IN.)	16		4
26	10	11967 1	BOLT (7/16-14 X 3 IN.)	4		4
27	10	11966	BOLT (7/16-14 X 3-3/4 IN.)	14		4
-	27	861246A98	GASKET SET-ENGINE OVERHAU	1		