



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	22	805328	1 ELBOW-90 DEG. (1/8 IN.)	1		
2	22	805059	BUSHING-REDUCER	1		
3		815425T	SENDER-OIL PRESSURE	1		
3		37293T	SENDER-OIL PRESSURE (DUAL : OPT			
4		97257A	1 SENDER-WATER TEMPERATUR	1		
4		49734	SENDER-WATER TEMPERATUR	OPT		
5	13	26996	LOCKWASHER (#10)	2		
6	11	68219	NUT (#10-32)	2		
7	87	805605A	1 SWITCH-OIL PRESSURE	1		
8		816492A	6 ALARM KIT	1		
9	84	95084A	9 CABLE ASSEMBLY	1	BRAVO ENGINES	
10	88	79091	FUSE (20 AMP)	1	BRAVO ENGINES	
11	84	95084A	10 CABLE ASSEMBLY	1	BRAVO ENGINES	
12		805592A	1 CONNECTOR	1	BRAVO ENGINES	
13		806612T	SENSOR-KNOCK	1		
14		805218T	SENSOR-COOLANT TEMPERATL	1		
15	22	806705	1 FITTING-Y	1		4
16		805223T	SENSOR-MAT	1		