



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		<b>92497A 3</b>	<b>ALTERNATOR ASSEMBLY (55 AM</b>	<b>1</b>		
1	390	7027	NUT	1		
2	390	7033	LOCKWASHER	1		
3	390	8637	PULLEY	1		
4	390	7004	FAN	1		
5		813969	SPACER	1		
6	390	7028	NUT	4		
7	390	7000	FRONT COVER	1		
8	390	7005	BALL BEARING	2		
9	390	7006	RETAINER	1		
10	390	8636	STATOR ASSEMBLY	1		
11	390	7009	DIODE RECTIFIER	1		
12	390	7010	HEAT SINK	1		
13	390	7020	SLEEVE	1		
14	390	7018	SLEEVE	1		
15	390	7034	KEY	1		
16	390	8635	ROTOR ASSEMBLY	1		
17	390	7014	SLIP RING	1		
18	390	7206	WASHER	1		
19	390	7207	LOCKWASHER	1		
20	390	7029	SCREW	1		
21	390	7007	RETAINER	1		
22	390	7003	REAR COVER	1		
23		813972	CONDENSER	1		
24	390	7023	WASHER	1		
25	390	7024	WASHER	1		
26	390	7025	NUT	1		
27	390	7208	WASHER	1		
28	390	7032	LOCKWASHER	2		
29	390	7026	NUT	1		
30	390	7022	WASHER	1		
31	390	8638	THRU BOLT	4		
32	390	7021	NUT	1		
33	390	7011	BRUSH HOLDER ASSEMBLY	1		
34	390	7030	SCREW (1/2 IN.)	2		
35	390	7008	DIODE TRIO	1		
36	390	7019	SPACER	1		
37	390	7013	GASKET	1		
38		808534	VOLTAGE REGULATOR	1		
39	390	7015	SCREW	4		