



19900

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		62285	BRACKET, MOUNTING (REAR)	2		
1		52158A20	BRACKET, MOUNTING (REAR)(R)	1		
2	10	47462	SCREW, (.437-14 x 1.250), MOUN	4		
3	13	32993	LOCKWASHER, (.437), MOUNTIN	4		
4	10	47654	SCREW, (.437-14 X 2.75), CLAMP	2		
5	13	32993	LOCKWASHER, (.437), CLAMPIN	2		
6	54	47528	CLAMP, ADJUSTING TRUNNION	4		
7	11	29553	NUT, (.437-14), SCREW CLAMP	2		
8		71128A 2	BRACKET, MOUNTING-ENGINE (I	2		
9	10	68101	SCREW, (.375-16 x 1.375), MOUN	5		
9	10	34354	SCREW, (.375-16 x 1.50), MOUNT	1		
10	13	35048	LOCKWASHER, (.375), MOUNTIN	6		
11	10	57357	SCREW, (.437-13 x 2.250), CLAMP	2		
12	13	32993	LOCKWASHER, (.437), CLAMPIN	2		
13	11	29553	NUT, (.437-14), CLAMPING SCRE	2		
14		66166A 4	TRUNNION, ADJUSTING-MOUNT	4		
15	13	68102	LOCKWASHER, (.750), MOUNTIN	4		
16		66284A 2	BASE ASSEMBLY, ENGINE MOUN	4		
17	11	20739	NUT, (.750-16), JAM-ENGINE MC	8		
18	14	66658	TAB WASHER, ENGINE MOUNT	4		