



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		90747A27	DISTRIBUTOR	1	1
1		805185A26	DISTRIBUTOR	1	4
2		805759A 2	CAP	1	
3	10	90926	SCREW	4	
4	27	805760	GASKET	1	
5		13524A 5	ROTOR/SENSOR WHEEL	1	
6	87	91019A 3	SENSOR ASSEMBLY	1	1
7	13	26996	LOCKWASHER	2	1
8	11	68219	NUT	2	1
9	87	91019A 6	SENSOR ASSEMBLY	1	4
10	10	66686	SCREW (1")	1	
10	10	72202	SCREW (1-1/4")	1	
11	43	818807	DRIVE GEAR	1	
12	17	47617	PIN	1	
13	23	90915	BUSHING	2	
14	12	90931	WASHER	1	
15	27	34486 3	GASKET	1	3
16		52185	CLAMP	1	
17	10	806681	SCREW	1	
18	84	816761A 4	SPARK PLUG WIRE KIT	1	1
18	84	816761A17	SPARK PLUG WIRE KIT	1	4
19	85	63709A 1	BOOT ASSEMBLY	8	
20	33	59571	SPARK PLUG	8	
21		54676	RETAINER (2 WIRE)	2	
22		32783	RETAINER (3 WIRE)	2	
23	392	805570A 2	IGNITION COIL	1	
24		77294T	BRACKET	1	
25	10	41408	SCREW (1-1/2")	1	
26	13	26996	LOCKWASHER	2	
27	11	68219	NUT	2	
28	10	86750	SCREW (5/8")	2	
29	13	26996	LOCKWASHER	2	
30	12	20084	WASHER	2	
31	16	90096A 1	STUD ASSEMBLY	2	
32	54	72821	RETAINER	2	
-	27	75611A88	ENGINE OVERHAUL GASKET SE	1	