



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		97401A 8	FUEL PUMP	1		
2	27	34213	GASKET	1		3
3	10	34354	SCREW (1-1/2 IN.)	2		
4	13	35048	LOCKWASHER	2		
5		35373	MOUNTING PLATE	1		
6	27	34898	GASKET	1		3
7	10	35366	SCREW	2		
8		35377	PUSH ROD	1		
9		89876A 3	BASE ASSEMBLY	1		
10	22	816133 1	FITTING	1		
11	22	32561	PIPE PLUG	2		
12		88641	MOUNTING BRACKET	1		
13	10	26065	SCREW	2		
14	11	35814	NUT	2		
15	35	807172	FUEL FILTER/WATER SEPARATI	1		
16	22	33821	CONNECTOR (USE WITH WEDGE)	3		
16	22	33821	CONNECTOR USE WITH SPACEF	2		
17	22	43276	ELBOW	1		
18	32	97326T	FUEL LINE	1		
19	32	805542T	FUEL LINE (WEDGE MOUNTING)	1		
19	32	805360T	FUEL LINE (SPACER MOUNTING)	1		
20	32	73815 67	HOSE	1		
-	27	75611A88	ENGINE OVERHAUL GASKET SE	1		