



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		66417T	BRACKET (REAR)	2	BORG WARNER	
2	10	37269	SCREW (2")	4	BORG WARNER	
3	13	32993	LOCKWASHER	4	BORG WARNER	
4	10	57357	SCREW (2-1/4")	2	BORG WARNER	
5	13	32993	LOCKWASHER	2	BORG WARNER	
6	11	29553	NUT	2	BORG WARNER	
7		18903T	BRACKET (REAR)	2	HURTH	
8	10	806195	SCREW	8	HURTH	
9	13	38829	LOCKWASHER	8	HURTH	
10	10	57357	SCREW (2-1/4 IN.)	4	HURTH	
11	13	32993	LOCKWASHER	4	HURTH	
12	11	29553	NUT	4	HURTH	
13		71128A 2	BRACKET (FRONT)	2		
14	10	68101	SCREW (1-3/8")	6		
15	13	35048	LOCKWASHER	6		
16	10	57357	SCREW	2		
17	13	32993	LOCKWASHER	2		
18	11	29553	NUT	2		
19		66166A 4	TRUNNION	4		
20	13	68102	LOCKWASHER	4		
21		66284A 2	BASE ASSEMBLY	2	ENGINE	
22	11	20739	JAM NUT	2	ENGINE	
23	14	66658	TAB WASHER	2	ENGINE	
24		816326A 2	BASE ASSEMBLY	2	TRANSMISSION	
25	11	816331	NUT	2	TRANSMISSION	
26	14	66658	TAB WASHER	2	TRANSMISSION	
27	11	20739	JAM NUT	4		