



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-	50	76965A 3	STARTER (L.H. ROTATION)	1		
-	50	79604A 3	STARTER (R.H. ROTATION)	1		
1		79206	HOUSING	1		
2	23	33369	BUSHING	1		
3		814474	COLLAR	1		
4	53	33290	RING-RETAINING	1		
5		33291	COLLAR	1		
6		68608	DRIVE (L.H. ROTATION)	1		
6		68609	DRIVE (R.H. ROTATION)	1		
7		79396	PLATE	1		
8	23	71694	BUSHING	1		
9	12	68614	WASHER	1		
10	10	75659	SCREW	2		
11		68606	ARMATURE (L.H. ROTATION)	1		
11		68607	ARMATURE (R.H. ROTATION)	1		
12		NSS	SHOE-POLE (DELCO REMY #81	4		6
13		NSS	SCREW (DELCO REMY #19683	4		6
14		NSS	GROMMET (DELCO REMY #184	1		6
15		NSS	FIELD COIL (L.H. ROTATION) (D	1		6
15		75664	FIELD COIL (R.H. ROTATION)	1		
16	12	33258	WASHER-LEATHER	1		
17		79211	FRAME-COMMUTATOR END	1		
18		NSS	BOLT-THRU (DELCO REMY #19	1		6
18		NSS	BOLT-THRU (DELCO REMY #19	1		6
19		33284	HOLDER	2		
20		33283	HOLDER	2		
21		33270	BRUSH	4		
22		NSS	SCREW (DELCO REMY #19677	2		6
22		NSS	SCREW (DELCO REMY #44352	2		6
23		33294	SUPPORT PACKAGE	2		
24	24	33285	SPRING	4		
25		NSS	PIN-DOWEL (DELCO REMY #8C	1		6
26		33297	LEVER	1		
27		NSS	STUD (DELCO REMY #1814529	1		6
28	12	68615	WASHER	1		
29	11	26484	NUT	1		
30		33317	PLUNGER	1		
31	17	79207	PIN	1		
32	24	46889	SPRING	1		
33		NSS	SCREW (DELCO REMY #94132	2		6
34	99	18080	SOLENOID SWITCH	1		