



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	50	808011A 1	STARTER MOTOR ASSEMBLY	1	(SEE "STARTER MOTOR" FOR E	
2	10	47462	SCREW (7/16-14 X 1-1/4 IN.)	2		
3	13	32993	LOCKWASHER (7/16 IN.)	2		
4	11	15874	NUT (M10 X 1.5)	1		
5	11	40021 1	NUT (M5 X 0.8)	1		
6	13	26996	LOCKWASHER (#10)	1		
7	85	79695	BOOT-INSULATOR	1		
8		807652T	ALTERNATOR ASSEMBLY	1	(SEE "ALTERNATOR (MANDO)"	
9	12	96457	WASHER-PHENOLIC	1		
10	13	26996	LOCKWASHER (#10)	1		
11	11	79989	NUT (#10-24)	1		
12	13	26992	LOCKWASHER (1/4 IN.)	1		
13	11	94330	NUT (1/4-20)	1		
14		807750T	BRACE	1		
15	10	98261	SCREW (3/8-16 X 3/4 IN.)	1		
16	13	35048	LOCKWASHER (3/8 IN.)	1		
17	10	29198	SCREW & LOCKWASHER (5/16-1	1		
18		860370T 1	BRACKET-ALTERNATOR	1		
19	16	860102	STUD	3		
20	10	56743	SCREW (3/8-24 X 3-1/8 IN.)	1		
21	11	23161	NUT (3/8-24)	1		
22		807767T	BRACKET-IDLER ADJUSTMENT	1		
23	10	98261	SCREW (3/8-16 X 3/4 IN.)	1		
24	11	29250	NUT (5/16-24)	1		
25	43	818381 2	PINION STUD	1		
26		818380T	BUSHING	2		
27		807757T	PULLEY	2		
28	11	817618	NUT (7/16-20)	2		
29		807753T	BRACKET-IDLER	1		
30	11	32219	NUT (3/8-16)	3		
31	10	816601	SCREW (7/16-20 X 1-1/2 IN.)	1		