



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		72646	INTAKE MANIFOLD	1	
2	10	11976	BOLT, INTAKE MANIFOLD	9	
2		N.S.S.	BOLT, INTAKE MANIFOLD (GM #:	3	
3		42697	PLATE, PULLEY	1	
4	54	47512	EYE, LIFTING	1	
5	10	34354	SCREW, LIFTING EYE	2	
6		N.S.S.	STUD, GUARD TO INTAKE MANIF	4	
7		72647	GUARD, INTAKE MANIFOLD	1	
8	27	72637	GASKET SET, INTAKE MANIFOLD	1	4
9		60658	WATER PUMP ASSEMBLY	1	
10	27	34897	GASKET, WATER PUMP MOUNT	2	4
11	10	32132	SCREW, WATER PUMP TO CYLIND	2	
11	10	47688	SCREW, WATER PUMP TO CYLIND	1	
11	10	52200	SCREW, WATER PUMP TO CYLIND	1	
12		42799	PULLEY, WATER PUMP	1	
13	10	47277	SCREW, PULLEY TO WATER PUM	4	
14	13	39107	LOCKWASHER, WATER PUMP P	4	
15		75420	BALANCER, HARMONIC - CRANK	1	
16		33863	PULLEY, HARMONIC BALANCER	1	
17	10	72626	BOLT, PULLEY AND HARMONIC	1	
18	13	39131	LOCKWASHER, PULLEY AND HA	1	
19	12	35332	WASHER, PULLEY AND HARMON	1	
20	10	34352	BOLT, PULLEY (7/8")	3	
21	13	35048	LOCKWASHER, PULLEY BOLT	3	
22	57	49213A	BELT, ALTERNATOR DRIVE (44"	1	
23		75435A	POINTER, TIMING	1	
24		35365	SUPPORT, SPARK PLUG LEAD W	2	
25	10	35366	SCREW, LEAD WIRE SUPPORT	2	
26		60660A	COVER ASSEMBLY, CRANKCASE	1	9
26		13613	COVER ASSEMBLY, CRANKCASE	1	9
27	26	97335	OIL SEAL, COVER	1	4,9
28	27	14250	GASKET, CRANKCASE FRONT EN	1	4,9
26		14249A	COVER, CRANKCASE FRONT	1	8
27	26	97335	OIL SEAL, COVER	1	4,8
28		14249A	GASKET, COVER	1	4,8
29	10	35366	SCREW, COVER	10	
31		53338	FILTER VALVE	1	
32	10	54786	SCREW, FILTER VALVE TO CYLIND	2	
33		52731	OIL FILTER	1	
34		14239	RETAINER, OIL SEAL (REAR) L.H	1	8
35	26	14240	OIL SEAL, CRANKSHAFT (REAR)	1	4,8