



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	45	94819A 3	DRIVE SHAFT ASSEMBLY	1		
2		52504T	FLANGE	2		
3		61221	COVER AND BEARING KIT	2		
4	22	74036	GREASE FITTING	2		
5	10	805159	SCREW (1-1/2 IN.)	8		
6	11	34933	NUT	8		
7		42304A 2	BEARING SUPPORT ASSEMBLY	1		
8	26	93924	OIL SEAL	1		
9	30	93944A 1	BALL BEARING	1		
10	53	93914	SNAP RING	1		
11	22	74036	GREASE FITTING	1		
12		93908A 1	SHAFT ASSEMBLY	1	(INPUT)	
13	19	93921	EXPANSION PLUG	1		
14	53	93915	SNAP RING	1		
15	22	74036	GREASE FITTING	1		
16		93918A 1	SHIELD ASSEMBLY	2	(LOWER)	
17	10	76926	SCREW (7/8 IN.)	6		
18		93919A 1	SHIELD ASSEMBLY	2	(UPPER)	
19	10	96995	SCREW (7/8 IN.)	8		
20	11	68411	NUT	8		
21		93906A 2	SHAFT ASSEMBLY	1	(OUTPUT)	
22	25	25439	O-RING	2		
23	53	94104	SNAP RING	1		
24	30	62780A 1	BALL BEARING	1		
25		18643A 8	COUPLING ASSEMBLY	1		
26		18644	BUMPER	3		
27	10	14883	SCREW	3		
28	12	13510	WASHER	3		
29	23	49126	BUSHING	1		
30	53	94103	SNAP RING	1		
31	10	57053	BOLT (4-1/2 IN.)	2		
32	12	42307	WASHER (SPHERICAL)	4		
33	11	28040	NUT	2		
34	84	41575A 1	HARNES ASSEMBLY	1		