



CYLINDER HEAD AND ROCKER COVER

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		809395	COVER-ROCKER	2		
2	36	18710	1 CAP-OIL FILL	2		
3	10	17344	SCREW	8		
4	27	17467	GASKET-ROCKER COVER	2		3
5		99948	PUSH ROD	16	USE WITH FLAT LIFTER	
5		17339	1 PUSH ROD	16	USE WITH ROLLER LIFTER	
6		850095	VALVE-EXHAUST	8	(STANDARD)	
6		850096	VALVE-EXHAUST	AR	(.015 O.S.)	2
7		97661	VALVE-INTAKE	8	(STANDARD)	
7		97662	VALVE-INTAKE	AR	(.015 O.S.)	2
8	26	34217	SEAL-O-RING	16	(INTAKE AND EXHAUST)	3
9	26	97664	SEAL	8	(INTAKE)	3
10	26	852936	SEAL	8	(EXHAUST)	3
11	24	48347	SPRING	16		
12		34518	SHIELD	16		
13		48348	CAP	8	(INTAKE)	
14		11965	ROTATOR	8	(EXHAUST)	
15	28	54797	1 KEY	32		
16		35329	ARM KIT-ROCKER	16		
17		35331	BALL UNIT	16		
18	11	34516	NUT	16		
19	938	9718	HEAD ASSEMBLY-CYLINDER	2		
20	16	34522	STUD	AR	(.003 O.S.)	2
20	16	34521	STUD	AR	(.013 O.S.)	2
21	27	75611	GASKET	2		3
22	10	11968	BOLT (7/16-14 X 1-3/4 IN.)	16		
23	10	11967	1 BOLT (7/16-14 X 3 IN.)	4		
24	10	11966	BOLT (7/16-14 X 3-3/4 IN.)	14		
-	27	806871A96	GASKET SET-OVERHAUL	1	CONTENTS INDICATED BY FOO	