



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		806235A	1 HOUSING ASSEMBLY-THERMOSTAT	1		
2	22	32803	PLUG-PIPE (3/8 IN.)	2		
3	27	806871	GASKET-THERMOSTAT	1		2
4	27	53045	1 GASKET	1		2
5		807252	2 THERMOSTAT (160 DEG.)	1		
6	23	806922	SLEEVE	1		
7	10	98794	SCREW (3/8-16 X 1 IN.)	2		
8	32	808033	HOSE-THERMOSTAT HOUSING	1		
9	32	860089	HOSE-FUEL COOLER TO POWER	1		
10	32	807661	HOSE-POWER STEERING COOL	1		
11	54	815504222	CLAMP-HOSE	5		
12	54	815504212	CLAMP-HOSE	1		
13	32	87108	HOSE-THERMOSTAT HOUSING	1		
14	54	815504232	CLAMP	2		
15	32	860144	HOSE	1	THERMOSTAT HOUSING TO PC	
16	32	807697	HOSE	1	THERMOSTAT HOUSING TO ST	
17	54	815504220	CLAMP-HOSE	4		
18	54	47715	CLIP	1		
19	11	29250	NUT (5/16-24)	1		
20		807292T	COOLER-POWER STEERING OIL	1		
21		805546A	2 BRACKET-TRANSMISSION OIL C	1		
22		77223	3 PAD	1		
23	54	815504224	CLAMP	1		
24	10	816585	SCREW (5/16-18 X 7/8 IN.)	1		
-	27	75611A96	GASKET SET-ENGINE OVERHAU	1		