



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	45	86978A 1	DRIVESHAFT ASSEMBLY (37.00)	1		
1	45	53967A 1	DRIVESHAFT ASSEMBLY (43.00)	1		
2		61218	FLANGE	1		
3		61221	U JOINT KIT	2		
4	22	74036	FITTING-Grease	2		
5		96276A 2	YOKE ASSEMBLY (Part of 14750A)	1		
6		61218	FLANGE	1		
7	10	68743	SCREW (.437-20 x 1.250)	4		
8	13	47659	LOCKWASHER (.437)	4		
9	11	22024	NUT (.437-20)	4		
10		52505A 1	SHAFT ASSEMBLY-Drive Extensio	1		
11	19	47463	PLUG	1		
12	23	47471	BEARING	1		
13	10	60106	SCREW (.437-20 x 1.250)	4		
14	12	45176	WASHER	4		
15		55434A 2	HOUSING ASSEMBLY-Driveshaft	1		
16	26	52499	SEAL-Oil	1		
17	22	36382	PLUG-Pipe (.250)-Brass	1		
18	22	32802 1	PLUG-Pipe (.125)-Brass	1		
19	22	47902	FITTING	1		
20	15	49264A 1	SHIM SET-Driveshaft Housing	1		
21	30	47470	BEARING-Ball	1		
22	53	52502	RING-Snap	1		
23	27	52501	GASKET	1		
24		52506A 1	HOUSING ASSEMBLY-Bearing Suj	1		
25	31	47468	BEARING-Needle	1		
26	26	47465	SEAL-Oil	1		
27	53	52507	RING-Support	1		
28	53	52503	RING-Snap	1		
29	24	47755	SPRING-Yoke Guide	1		
30	10	32695	SCREW (.437-20 x 2.250)	4		
30	10	56393	SCREW (.437-20 x 1.750)	2		
30	10	32515	SCREW (.437-20 x 2.500)	2		
31	12	22248	WASHER	8		
32	11	35053	NUT (.437-20)	8		